

Single-phase Microinverter **USER MANUAL**

HMS-1600DW-4T
HMS-1800DW-4T
HMS-2000DW-4T

About Microinverter

This system is composed of a group of microinverters that convert direct current (DC) into alternating current (AC) and feed the power to the public grid. The system is designed for 4-in-1 microinverters, i.e., one microinverter is connected with four PV modules.

Each microinverter works independently so as to guarantee the maximum power generation of each PV module. This setup is highly flexible and reliable as the system enables direct control of the production of each PV module.

About the Manual

This manual contains important instructions for HMS-1600DW-4T/HMS-1800DW-4T/HMS-2000DW-4T microinverters and users shall read in its entirety before installing or commissioning the equipment. For safety reasons, only qualified technicians who have received training or demonstrated relevant skills can install and maintain this microinverter under the guidance of this document.

Other Information

Product information is subject to change without notice. User manual will be updated regularly, you may refer to the Hoymiles official website at www.hoymiles.com for the latest version.

CONTENTS

| | |
|--|-----------|
| 1. Important Notes | 4 |
| 1.1 Product Range | 4 |
| 1.2 Target Group | 4 |
| 1.3 Symbols Used | 4 |
| 1.4 Radio Interference Statement | 4 |
| 2. About Safety | 5 |
| 2.1 Important Safety Instructions | 5 |
| 2.2 Explanation of Symbols | 6 |
| 3. About Product | 7 |
| 3.1 About PV Microinverter System | 7 |
| 3.2 About Microinverter | 7 |
| 3.3 About 4-in-1 Unit | 8 |
| 3.4 Highlights | 8 |
| 3.5 Terminals Introduction | 9 |
| 3.6 Dimensions (mm) | 9 |
| 4. Installation Preparation | 10 |
| 4.1 Position and Space Required | 10 |
| 4.2 Connecting Multiple PV Modules to Microinverter | 10 |
| 4.3 Installation Tools | 11 |
| 4.4 AC Branch Circuit Capacity | 11 |
| 4.5 Precautions | 12 |
| 5. Microinverter Installation | 13 |
| 5.1 Accessories | 13 |
| 5.2 Installation Steps | 13 |
| 6. Troubleshooting | 18 |
| 6.1 Troubleshooting List | 18 |
| 6.2 LED Indicator Status | 21 |
| 6.3 Wireless Network Troubleshooting | 22 |
| 6.4 On-site Inspection (For qualified installers only) | 22 |
| 6.5 Routine Maintenance | 22 |
| 6.6 Microinverter Replacement | 23 |
| 7. Decommission | 24 |
| 7.1 Decommission | 24 |
| 7.2 Storage and Transportation | 24 |
| 7.3 Disposal | 24 |
| 8. Technical Data | 25 |
| 9. Appendix 1: | 26 |
| 9.1 Installation Map | 26 |
| 10. Appendix 2: | 27 |
| 10.1 WIRING DIAGRAM – 230VAC SINGLE PHASE: | 27 |
| 10.2 WIRING DIAGRAM – 230VAC / 400VAC THREE PHASE: | 28 |

1. Important Notes

1.1 Product Range

This manual describes the assembly, installation, commissioning, maintenance and troubleshooting of the following models of Hoymiles Microinverter:

- HMS-1600DW-4T
- HMS-1800DW-4T
- HMS-2000DW-4T




**Note: "1600" means 1600 W, "1800" means 1800 W, and "2000" means 2000 W.*

1.2 Target Group

This manual is only for qualified technicians. For safety purposes, only those who have been trained or demonstrate relevant skills can install and maintain this microinverter under the guidance of this document.

1.3 Symbols Used

The safety symbols in this user manual as shown below.

| Symbol | Description |
|---|---|
|  | This indicates a hazardous situation that can result in deadly electric shocks, other serious physical injuries, or fire incidents. |
|  | This indicates that directions must be strictly followed to avoid safety hazards including equipment damage and personal injury. |
|  | This indicates that the act is forbidden. You should stop, use caution and fully understand the operations explained before proceeding. |

1.4 Radio Interference Statement

This microinverter has been tested and complies with the requirements of CE EMC, meaning that it will not be affected by electromagnetic interference. Please note that incorrect installation may cause electromagnetic disturbances.

You can turn the equipment off and on to see if radio or television reception is interfered by this equipment. If this equipment does cause harmful interference to radio or television, please try the following measures to fix the interference:

- 1) Relocate other apparatus' antenna.
- 2) Move the microinverter farther away from the antenna.
- 3) Separate the microinverter and the antenna with metal/concrete materials or roof.
- 4) Contact your dealer or an experienced radio/TV technician for help.







2. About Safety

2.1 Important Safety Instructions

The HMS-1600DW-4T/HMS-1800DW-4T/HMS-2000DW-4T microinverter is designed and tested according to international safety requirements. However, certain safety precautions must be taken when installing and operating this inverter. The installer must read and follow all instructions, cautions and warnings in this installation manual.

- All operations including transportation, installation, start-up and maintenance must be carried out by qualified, trained personnel.
- Check the product before installation to make sure there is no damage caused during transportation because such damage can compromise the insulation integrity and safety clearances. Choose installation location carefully and adhere to specified cooling requirements. Unauthorized removal of necessary protections, improper use, incorrect installation and operation may cause damage to the equipment or incur serious safety and shock hazards.
- You should get necessary approvals from local power operator before connecting the microinverter to the power grid. This connection must be made only by qualified technical personnel. It is the responsibility of the installer to provide external disconnect switches and Over Current Protection Devices (OCPD).
- Each input of the inverter is connected to one PV module. Do not connect batteries or other sources of power supply. The inverter can be used only if all the technical parameters are observed and applied.
- Do not install the equipment in flammable, explosive, corrosive, extremely hot/cold, and humid environment. Do not use the equipment when safety devices in these environments are not working.
- Personal protective equipment such as gloves and goggles must be used during installation.
- Inform the manufacturer about non-standard installation conditions.
- Do not use the equipment if any operating anomalies are found.
- All repairs must be done with qualified spare parts which must be installed in accordance with their intended use and by a licensed contractor or authorized Hoymiles service representative.
- Liabilities arising from components that are not produced by Hoymiles are on the part of their respective manufacturers.
- Whenever the inverter has been disconnected from the public grid, please be extremely careful as some components can retain charge sufficient to create a shock hazard. Before touching any part of the inverter, please ensure the surface and the whole equipment are within the limit of safe temperature and voltage potential.
- Hoymiles is not liable for any damage caused by incorrect or improper operation.
- Electrical installation and maintenance shall be conducted by licensed electrician and shall comply with local wiring rules.


2.2 Explanation of Symbols

| Symbol | Usage |
|---|--|
|  | Treatment To comply with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Any device no longer needed must be returned to an authorized dealer or approved collection and recycling facility. |
|  | Caution Do not come within 8 inches (20 cm) of the microinverter when it is in operation. |
|  | Danger of high voltage High voltage in the microinverter can cause dangers to life. |
|  | Beware of hot surface The inverter can become hot during operation. Avoid contact with metal surfaces during operation. |
|  | CE mark The inverter complies with the Low Voltage Directive for the European Union. |
|  | Read manual first Please read the installation manual first before installation, operation and maintenance. |

3. About Product

3.1 About PV Inverter System

The four key elements of a typical grid-tied PV inverter system are PV modules, PV inverter, meter and power grid, as shown below. PV inverter converts the DC power generated by PV modules into AC power that meets the requirements of the power grid. The AC power is then fed into the grid via meter.



3.2 About Microinverter


PV Microinverter is a module-level solar inverter that tracks the maximum DC power point of each PV module, which is known as Maximum Power Point Tracking (MPPT).

Hoymiles new generation microinverter HMS-2000DW series is designed to accommodate high-powered PV modules, with maximum output power up to 2000 VA and maximum DC input current up to 16 A.

The MPPT circuit of HMS-2000DW-4T series microinverter is less susceptible to partial shade situations. With dual MPPT, when one MPPT fails or is shaded, the other MPPT can operate the unshaded string at maximum efficiency point, ensuring the inverter an optimum performance under different partial shading.

Hoymiles HMS-2000DW-4T series microinverter also features module-level monitoring. All microinverter data will be collected and sent to Hoymiles monitoring platform S-Miles Cloud via Wi-Fi.

Moreover, HMS-2000DW-4T series microinverter only carries a few dozen volts of DC voltage, which reduces safety hazards to the greatest extent.




Note:

Wi-Fi booster is a repeater (also known as Wi-Fi signal amplifier), mainly used to extend the range of Wi-Fi networks. When there is a large office area or a large home, Wi-Fi booster can expand your Wi-Fi system's coverage area by boosting or amplifying the wireless signal. It eliminates the dead spots to reach the signals to the destination.

3.3 About 4-in-1 Unit

Microinverters can be divided into 1-in-1, 2-in-1, 4-in-1, etc., depending on how many PV modules are connected to them. This means that the microinverter can connect to one module, two modules and four modules respectively, as shown below.




This manual is about Hoymiles 4-in-1 microinverter HMS-2000DW series. Its innovative 4-input design enables faster installation and lower cost, and makes the HMS-2000DW series a very cost-effective choice. Each microinverter connects to four PV modules at most with module-level monitoring, enabling greater energy harvest and easier maintenance.

3.4 Highlights


- Maximum output power up to 1600/1800/2000 W
- Peak efficiency 96.70%
- Static MPPT efficiency 99.80%, Dynamic MPPT efficiency 99.76% in overcast weather
- Built-in Wi-Fi module enables quicker and easier installation and commissioning
- The industrial-grade Wi-Fi module brings higher microinverter reliability
- Power factor (adjustable) 0.8 leading ... 0.8 lagging
- High reliability: IP67 (NEMA 6) enclosure, 6000 V surge protection
- Connect directly to the home router, no gateway is required

3.5 Terminals Introduction



| Object | Description |
|--------|-------------------------|
| A | DC Connectors |
| B | Wi-Fi Wireless Terminal |
| C | AC Sub Connector |

3.6 Dimensions (mm)



4. Installation Preparation

4.1 Position and Space Required

Please install the microinverter and all DC connections under the PV module to avoid direct sunlight, rain exposure, snow buildup, UV etc. The silver side of the microinverter should be up and facing the PV module.


Leave a minimum of 2 cm of space around the microinverter enclosure to ensure ventilation and heat dissipation.

4.2 Connecting Multiple PV Modules to Microinverter

General Guidelines:

- 1. PV modules should be connected to DC input ports of a microinverter.
- 2. Use DC extension cable when the original cable is not long enough. Please consult the local power operator to make sure that the DC cable complies with local regulations.

Two typical wiring methods are shown below.



| | |
|---|--------------------|
| A | PV module |
| B | DC extension cable |
| C | Microinverter |

Note:

The voltage of modules (considering the effect of local temperature) must not exceed the maximum input voltage of the microinverter. Otherwise, the microinverter may be damaged (refer to the Technical Data section to determine the absolute maximum input voltage).

4.3 Installation Tools

Besides the tools recommended below, other auxiliary tools can also be used on-site.

| | |
|-------------------------------|------------------------------|
| Screwdriver | Multimeter |
| Socket Wrench or Allen wrench | Marker pen |
| Diagonal pliers | Steel tap |
| Wire cutters | Cable tie |
| Wire stripper | Torque and adjustable wrench |
| Utility knife | |

| | |
|--------------------|--------------|
| Safety glove | Dust masks |
| Protective goggles | Safety shoes |

4.4 AC Branch Circuit Capacity

Hoymiles HMS-1600DW-4T/HMS-1800DW-4T/HMS-2000DW-4T can be used with 12AWG or 10AWG AC Trunk Cable and the AC Trunk Connector which are provided by Hoymiles. The number of microinverters on each 12AWG or 10AWG AC branch shall not exceed the limit as shown below.

| | HMS-1600DW-4T | HMS-1800DW-4T | HMS-2000DW-4T | Maximum over current protection device (OCPD) |
|---------------------------------|-------------------------------|-------------------------------|-------------------------------|---|
| Maximum number per 12AWG branch | 2@220 V 2@230 V 2@240 V | 2@220 V 2@230 V 2@240 V | 2@220 V 2@230 V 2@240 V | 20 A |
| Maximum number per 10AWG branch | 4@220 V 4@230 V 4@240 V | 3@220 V 4@230 V 4@240 V | 3@220 V 3@230 V 3@240 V | 32 A |

Note:

- The number of microinverters that can be connected to each AC branch is determined by the ampacity (also known as current-carrying capacity) of the cable.
- 1-in-1, 2-in-1 and 4-in-1 microinverters can be connected to the same AC branch, as long as the total current does not exceed the ampacity specified in local regulations.

4.5 Precautions

The equipment is installed based on the system design and the location of installation.


- | |
|--|
| <ul style="list-style-type: none">• The installation must be done with the equipment disconnected from the grid (power disconnect switch open) and with the PV modules shaded or isolated. |
| <ul style="list-style-type: none">• Make sure the environmental conditions fit the microinverter's requirement (degree of protection, temperature, humidity, altitude, etc.) as specified in the Technical Data section. |
| <ul style="list-style-type: none">• Avoid direct sunlight to prevent power derating which can be caused by an increase in the internal temperature of the microinverter. |
| <ul style="list-style-type: none">• Keep the inverter in well-ventilated place to avoid overheating. |
| <ul style="list-style-type: none">• Keep the inverter away from gases or flammable substances. |
| <ul style="list-style-type: none">• Avoid electromagnetic interference because it can compromise the normal operation of electronic equipment. |

Installation location shall meet the following conditions:

- | |
|---|
| <ul style="list-style-type: none">• Install only on structures specifically designed for PV modules (supplied by installation technicians). |
| <ul style="list-style-type: none">• Install microinverter underneath PV modules to make sure it works in the shadow. Nonobservance may cause the derating of inverter production. |

5. Microinverter Installation

5.1 Accessories



| | Description |
|---|--|
| A | AC Trunk Cable, 12/10 AWG Cable |
| B | M8 × 25 screws (Prepared by the installer) |
| C | Grounding Accessory |
| D | AC Trunk Connector |
| E | AC Trunk Port Cap |
| F | AC Trunk Port Disconnect Tool |
| G | AC Trunk End Cap |
| H | AC Trunk Connector Unlock Tool |
| <i>*Note: All accessories above are not included in the package and should be purchased separately.</i> | |

5.2 Installation Steps

The order of Step 1 and Step 2 can be reversed according to your planned needs.

Step 1. Plan and Install the Microinverter


A) Mark the position of each microinverter on the rail according to the PV module layout.

B) Fix the screws on the rail.

C) Hang the microinverter (label side up) on the screws and beneath the PV module. Then tighten the screws.

Mounting Torque : 9 N·m

The AC cable contains earth wire, so grounding can be done directly with it. For regions that have special requirements, we offer optional grounding brackets that can be used to complete the external grounding.




Route a continuous grounding cable through grounding brackets for each microinverter to the AC grounding electrode that conforms with local regulations.

Torque each grounding cleat screw to 2 N·m.

Note:

- Microinverter installation and DC connections must be done under the PV module to avoid direct sunlight, rain exposure, snow buildup, UV etc.
- Leave a minimum of 2 cm of space around the microinverter enclosure to ensure ventilation and heat dissipation.
- Mounting torque of the 8 mm screw is 9 N·m. Do not over-torque.
- Do not pull or hold the AC cable with your hand. Hold the handle instead.




Step 2. Plan and Build the AC Trunk Cable

AC Trunk Cable is used to connect the microinverter to the power distribution box.

- Select the appropriate AC Trunk Cable according to the spacing between microinverters. The connectors of the AC Trunk Cable should be spaced based on the spacing between microinverters to ensure that they can be properly matched. (Hoymiles provides AC Trunk Cable with different AC Trunk Connector spacing.)
- Determine how many microinverters you plan to install on each AC branch and prepare AC Trunk Connectors accordingly.
- Take out segments of AC Trunk Cable as you need to make AC branch.
 - Disassemble the AC Trunk Connector and remove the cable.

- Unlock the connector's upper cover with AC Trunk Connector Unlock Tool.




- Loosen the three screws with the screwdriver. Untighten the cap and remove the cable.




2) Install the AC Trunk End Cap at one side of AC Trunk Cable (the end of AC Trunk Cable).

- Insert the AC Trunk End cap and screw the cap back to port, then tighten the cap.




- Plug the upper cover back to the Trunk connector.




3) Install AC end cable on the other side of AC Trunk Cable (connected to the distribution box).


- Unlock the port upper cover, loosen the screws with the screwdriver and remove the extra cable. (Skip this step if there is no cable at this side.)




- Prepare a segment of AC cable of suitable length to connect to the distribution box, with stripping requirements fulfilled.




- Insert the cable into the cap in a way that the L, N and PE are in corresponding slots.



- Tighten the screws, and then tighten the cap back to the port.



- Plug the upper cover back to the Trunk connector.




Note:

- Tightening torque of the cap: 4.0 ± 0.5 N·m. Please do not over-torque.
- Torque of locking screw: 0.4 ± 0.1 N·m.
- Do not damage the sealing ring in the AC Trunk Connector during disassembly and assembly.
- Wires used in Hoymiles Microinverter:


PE (Green-yellow)



N (Blue)




L (Brown)




D) Repeat the above steps to make all the AC Trunk Cables you need. Then lay out the cable on the rail as appropriate so that the microinverters can be connected to the Trunk connectors.

E) Attach the AC Trunk Cable to the mounting rail and fix the cable with tie wraps.




Step 3. Complete the AC Connection

- A) Plug the AC Sub Connector of the microinverter into the AC Trunk Connector until you hear the click.




- B) Connect the AC end cable to the distribution box, and wire it to the local grid network.

- C) Please plug the AC Trunk Port Cap in any vacant AC Trunk Port to make it water- and dust-proof.





Note:

- Make sure that the AC Trunk Connectors are kept away from any drainage channels.
- In case you need to remove the microinverter AC cable from AC Trunk Connector, insert the AC Trunk Port Disconnect Tool into the side of AC Sub Connector to complete the removal.




Step 4. Create an Installation Map

- A) Peel the removable serial number label from each microinverter.
- B) Affix the serial number label to the respective location on the installation map (please refer to the appendix).



Step 5. Connect PV Modules

- A) Mount the PV modules above the microinverter.
- B) Connect the PV modules' DC cables to the DC input side of the microinverter.



Step 6. Energize the System


- A) Turn on the AC breaker of the branch circuit.
- B) Turn on the main AC breaker of the house. Your system will start to generate power in about two minutes.

Note:

- Make sure that the AC Trunk Connectors are kept away from any drainage channels.
- In case you need to remove the microinverter AC cable from AC Trunk Connector, insert the AC Trunk Port Disconnect Tool into the side of AC Sub Connector to complete the removal.


Step 7. Set Up Monitoring System

- A) Scan the QR code to download the S-Miles Installer application.



- B) Connect the microinverter to the the network using S-Miles Installer application.

- Open the **S-Miles Installer** App on smartphone/tablet and login as Installer.
- Tap **O&M** icon on the bottom of the page, then tap **Network Config** button. This takes you to the network configuration screen.
- On **WLAN** setting, select the microinverter's hotspot and tap **Connect** button. (The network name of the microinverter consists of **DTUBI** and last six numbers of the serial number, and the default password is **12345678**.)




Note:


- If you already have an installer account, just type your account number and password to log in, otherwise, please ask your installer or distributor to create an account for you.

C) Set up with the Internet.

- When the connection is successful, turn to the **O&M** screen and tap **Network Config** icon.
- On the **Network Config** screen, tap the dropdown icon and a Wi-Fi network list will pop up.
- Select the router Wi-Fi from the list and enter the password.
- Tap the **Send to DTU** button.



- The network configuration takes about 1 minute, please be patient.
- If there is a faulty Wi-Fi connection, please check the internet as instructed.
- Check the indicator light of the microinverter. A Solid green light means a successful connection.



Note:

If your configuration page is inconsistent with the above, please update the microinverter firmware to the latest version.

Please refer to the **S-Miles Cloud Operating Guide** to set up monitoring system.

6. Troubleshooting

Adhere to all the safety measures described throughout this manual. Qualified personnel can use the following troubleshooting steps if the microinverter system does not operate correctly.

6.1 Troubleshooting List


| Code | Alarm range | Alarm status | Handling suggestions |
|------|-------------|------------------------------------|---|
| 121 | | Over temperature protection | <ol style="list-style-type: none"> 1. Check the ventilation and ambient temperature at the microinverter installation location. 2. If the ventilation is poor or the ambient temperature exceeds the limit, please improve the ventilation and heat dissipation. 3. If the problem persists when ventilation and ambient temperature are appropriate, contact your dealer or Hoymiles technical support team. |
| 124 | | Shut down by remote control | <ol style="list-style-type: none"> 1. Check the status of zero export management and whether the microinverters were manually shut down. 2. If the alarm still persists, please contact your dealer or Hoymiles technical support team. |
| 125 | | Grid configuration parameter error | <ol style="list-style-type: none"> 1. Check if the grid configuration parameter is correct and upgrade. 2. If the fault still exists, contact your dealer or Hoymiles technical support team. |
| 127 | | Firmware error | <ol style="list-style-type: none"> 1. Check if the firmware is correct and has been upgraded. 2. Check the communication between microinverter and Hoymiles monitoring system. Then try again. 3. If the fault still exists, contact your dealer or Hoymiles technical support team. |
| 129 | | Abnormal bias | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally and the microinverter can still work normally, no special treatment is required. 2. If the alarm occurs frequently and cannot be recovered, contact your dealer or Hoymiles technical support team. |
| 130 | | Offline | <ol style="list-style-type: none"> 1. Please make sure that the microinverter works normally (check if the DC voltage is within normal range and confirm the status of the LED indicator). 2. Check if the SN on microinverter label is the same as on the monitoring platform. 3. If the alarm occurs frequently and cannot be recovered, contact your dealer or Hoymiles technical support team. |
| 141 | Grid | Grid overvoltage | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the grid voltage may be just abnormal temporarily. The microinverter can automatically recover after grid voltage becomes normal. 2. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If not, contact the local power operator or change the grid overvoltage protection limit in the grid profile via Hoymiles monitoring system with the consent of the local power operator. |
| 142 | Grid | 10 min value grid overvoltage | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the grid voltage may be just abnormal temporarily. The microinverter can automatically recover after grid voltage becomes normal. 2. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If not, contact the local power operator or change the grid overvoltage protection limit via Hoymiles monitoring system with the consent of the local power operator. |

| | | | |
|-----|--------|----------------------------------|--|
| 143 | Grid | Grid undervoltage | <p>1. If the alarm occurs occasionally, the grid voltage may be just abnormal temporarily. The microinverter can automatically recover after grid voltage becomes normal.</p> <p>2. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If not, contact the local power operator or change the grid undervoltage protection limit in the grid profile via Hoymiles monitoring system with the consent of the local power operator.</p> <p>3. If the fault still exists, check the AC switch or AC wiring.</p> |
| 144 | Grid | Grid overfrequency | <p>1. If the alarm occurs occasionally, the grid frequency may be just abnormal temporarily. The microinverter can automatically recover after grid frequency becomes normal.</p> <p>2. If the alarm occurs frequently, check whether the grid frequency is within the acceptable range. If not, contact the local power operator or change the grid overfrequency protection limit via Hoymiles monitoring system with the consent of the local power operator.</p> |
| 145 | Grid | Grid underfrequency | <p>1. If the alarm occurs occasionally, the grid frequency may be just abnormal temporarily. The microinverter can automatically recover after grid frequency becomes normal.</p> <p>2. If the alarm occurs frequently, check whether the grid frequency is within the acceptable range. If not, contact the local power operator or change the grid underfrequency protection limit via Hoymiles monitoring system with the consent of the local power operator.</p> |
| 146 | Grid | Rapid grid frequency change rate | <p>1. If the alarm occurs occasionally, the grid frequency may be just abnormal temporarily. The microinverter can automatically recover after grid frequency becomes normal.</p> <p>2. If the alarm occurs frequently, check whether the grid frequency change rate is within the acceptable range. If not, contact the local power operator or change the grid frequency change rate limit in the grid profile in the grid profile via Hoymiles monitoring system with the consent of the local power operator.</p> |
| 147 | Grid | Power grid outage | Please check whether the AC switch, branch breaker and AC wiring is normal. |
| 148 | Grid | Grid disconnection | Please check whether the AC switch, branch breaker and AC wiring is normal. |
| 149 | Grid | Island detected | <p>1. If the alarm occurs occasionally, the grid frequency may be just abnormal temporarily. The microinverter can automatically recover after grid voltage becomes normal.</p> <p>2. If the alarms occur frequently on all the microinverters in your station, contact the local power operator to check whether there is a grid island.</p> <p>3. If the alarm still exists or happens on only several microinverters, please contact your dealer or Hoymiles technical support.</p> |
| 205 | MPPT-A | Input overvoltage | <p>1. Please make sure that the PV module open-circuit voltage is less than or equal to the maximum input voltage.</p> <p>2. If the PV module open-circuit voltage is within the normal range, contact your dealer or Hoymiles technical support team.</p> |
| 206 | MPPT-B | Input overvoltage | <p>1. Please make sure that the PV module open-circuit voltage is less than or equal to the maximum input voltage.</p> <p>2. If the PV module open-circuit voltage is within the normal range, contact your dealer or Hoymiles technical support team.</p> |
| 207 | MPPT-A | Input undervoltage | <p>1. Please make sure that the PV module open-circuit voltage is not lower than minimum input voltage.</p> <p>2. If the PV module open-circuit voltage is within the normal range, contact your dealer or Hoymiles technical support team.</p> |

| | | | |
|-----------------|--------|-----------------------------|--|
| 208 | MPPT-B | Input undervoltage | 1. Please make sure that the PV module open-circuit voltage is not lower than minimum input voltage. 2. If the PV module open-circuit voltage is within the normal range, contact your dealer or Hoymiles technical support team. |
| 209 | PV-1 | No input | 1. Please confirm whether this port is connected to the PV module. 2. If the PV module is connected, please check the DC cable connection between this port and the PV module. |
| 210 | PV-2 | No input | 1. Please confirm whether this port is connected to the PV module. 2. If the PV module is connected, please check the DC cable connection between this port and the PV module. |
| 211 | PV-3 | No input | 1. Please confirm whether this port is connected to the PV module. 2. If the PV module is connected, please check the DC cable connection between this port and the PV module. |
| 212 | PV-4 | No input | 1. Please confirm whether this port is connected to the PV module; 2. If the PV module is connected, please check the DC cable connection between this port and the PV module. |
| 213 | MPPT-A | PV-1 & PV-2 abnormal wiring | 1. Please check whether the DC connections on port 1 and 2 are correct. 2. Check if the DC extension cable is made correctly. |
| 214 | MPPT-B | PV-3 & PV-4 abnormal wiring | 1. Please check whether the DC connections on port 3 and 4 are correct. 2. Check if the DC extension cable is made correctly. |
| 215 | PV-1 | Input overvoltage | Check the input voltage of PV-1 port. |
| 216 | PV-1 | Input undervoltage | Check the input voltage of PV-1 port. |
| 217 | PV-2 | Input overvoltage | Check the input voltage of PV-2 port. |
| 218 | PV-2 | Input undervoltage | Check the input voltage of PV-2 port. |
| 219 | PV-3 | Input overvoltage | Check the input voltage of PV-3 port. |
| 220 | PV-3 | Input undervoltage | Check the input voltage of PV-3 port. |
| 221 | PV-4 | Input overvoltage | Check the input voltage of PV-4 port. |
| 222 | PV-4 | Input undervoltage | Check the input voltage of PV-4 port. |
| 301 - 314 | | Device failure | 1. If the alarm occurs occasionally and the microinverter can still work normally, no special treatment is required. 2. If the alarm occurs frequently and cannot be recovered, contact your dealer or Hoymiles technical support team. |

6.2 LED Indicator Status

The LED flashes five times at start-up. All green flashes (1s gap) indicate normal start-up.



(1) During Start-up

- Flashing green five times (0.3s gap): Start-up success
- Flashing Red five times (0.3s gap): Start-up failure

(2) During Operation

- Fast green flashes (1s gap): Producing power
- Slow green flashes (2s gap): Producing power but one input is abnormal
- Red flashes (0.5s gap): Invalid AC grid or hardware failure. Refer to Hoymiles Monitoring Platform for more details
- Red flashes (1s gap): Not producing power due to invalid AC grid
- Solid red: Hardware failure. Please refer to Hoymiles Monitoring Platform for more details

(3) Other Status

- Red and Green flashes alternately: Firmware is broken

Note:

The microinverter is powered by DC side. If the LED light is not on, please check the DC side connection. If the connection and input voltage are normal, contact your dealer or Hoymiles Technical Support Team.

6.3 Wireless Network Troubleshooting


If there is a poor Wi-Fi signal strength indicated with signal bars in the S-Miles Installer application or if the S-Miles Cloud/S-Miles Installer application sometimes not displaying data, the problem could be the microinverter system's Wi-Fi connection.

To troubleshoot this problem, please follow the procedure listed below.

| Description | Procedure | | | | | | | | |
|--|--|-----------------------|-----------|---------|-----------|----------------|----------|---------|-----|
| An Unstable Internet Connection icon next to the plant name has been displayed in the S-Miles Installer application. | <p>Microinverter:</p> <ol style="list-style-type: none"> Restart the microinverter via the S-Miles Cloud webpage or S-Miles Installer application. If the Wi-Fi signal strength is still weak, go to check the router. <p>Router:</p> <ol style="list-style-type: none"> Check whether the router is using the 2.4G band, 5G band or using both 2.4G and 5G bands. If the router is using 2.4G band or using both 2.4G and 5G bands, proceed to step 2. Otherwise, change the router from 5G to 2.4G, then back to the home page. If the unstable issue persists, proceed to step 2. Check the signal strength of the router by connecting your phone or other devices to it. If the signal strength in your phone (or other devices) is good, proceed to step 3. Otherwise, go to check the wireless environment. Reboot the router. <p>Wireless Environment:</p> <ol style="list-style-type: none"> Check the wireless environment of the PV plant with Wi-Fi scanning software: <ol style="list-style-type: none"> Check the signal strength of your wireless connection, and make sure there is an ideal signal strength based on the requirements for the network. If the signal strength is good (> -65 dBm), proceed to step b. If the signal strength is weak (< -65 dBm), try to move the router closer to the microinverters. After this, if the signal strength is still weak, proceed to step b. <table border="1"> <thead> <tr> <th>Signal Strength (dBm)</th><th>Qualifier</th></tr> </thead> <tbody> <tr> <td>> -30</td><td>Excellent</td></tr> <tr> <td>-30 to -65</td><td>Vey Good</td></tr> <tr> <td>> -65</td><td>Bad</td></tr> </tbody> </table> <ol style="list-style-type: none"> Check whether there is interference from other nearby wireless networks. If your wireless network is affected by Wi-Fi interference, try to conquer the Wi-Fi interference by manually changing the router to another Wi-Fi channel that no one else is using. Otherwise, proceed to step 2. Contact the network operator and ask about the network problems. Add a Wi-Fi booster to your network. If the Wi-Fi signal is still weak. | Signal Strength (dBm) | Qualifier | > -30 | Excellent | -30 to -65 | Vey Good | > -65 | Bad |
| Signal Strength (dBm) | Qualifier | | | | | | | | |
| > -30 | Excellent | | | | | | | | |
| -30 to -65 | Vey Good | | | | | | | | |
| > -65 | Bad | | | | | | | | |
| S-Miles Cloud or S-Miles Installer application sometimes not displaying data. | <ol style="list-style-type: none"> Repeat the preceding steps to check your network connection status. If the problem is persists, contact your installer. | | | | | | | | |







6.4 On-site Inspection (For qualified installers only)

Troubleshoot a malfunctioning microinverter according to the following steps.

| | |
|---|--|
| 1 | Check if the utility voltage and frequency are within the respective range shown in Technical Data section of this manual. |
| 2 | Check the connection to the utility grid. Disconnect the AC and the DC power. Please note that when the inverter is in operation, disconnect the AC power first to de-energize the inverter, and then disconnect the DC power. Re-connect the PV modules to the microinverter. LED will flash red to indicate normal DC connection. Re-connect the AC power. LED will flash green for five times to indicate normal DC and AC connection. Never disconnect the DC wires while the microinverter is producing power. Re-connect the DC module connectors and wait for five short LED flashes. |
| 3 | Check the interconnection between all the microinverters on the AC branch circuit. Confirm that each inverter is energized by the utility grid as described in the previous step. |
| 4 | Make sure that every AC breaker is functioning properly and is closed. |
| 5 | Check the DC connection between the microinverter and the PV module. |
| 6 | Make sure that PV modules' DC voltage is within the allowable range shown in the Technical Data section of this manual. |
| 7 | If the problem persists, please call Hoymiles customer support. |
|  | <u>Do not try to repair the microinverter by yourself. If the troubleshooting fails, please return it to the factory for replacement.</u> |

6.5 Routine Maintenance

1. Only authorized personnel are allowed to carry out the maintenance operations and are responsible for reporting any anomalies.
2. Always use personal protective equipment provided by the employer during maintenance operation.
3. During normal operation, check the environmental conditions regularly to make sure that the conditions have not changed over time and that the equipment is not exposed to adverse weather conditions and has not been obstructed.
4. DO NOT use the equipment if any problems are detected. Restore its working conditions after the fault is fixed.
5. Conduct annual inspections on various components, and clean the equipment with a vacuum cleaner or special brushes.

| | |
|---|---|
|  | Do not attempt to dismantle or repair the microinverter! No user-serviceable parts inside for the safety and insulation reasons! |
|  | The AC output wiring harness (AC drop cable on the microinverter) cannot be replaced. The equipment should be scrapped if the cord is damaged. |
|  | Maintenance operations must be carried out with the equipment disconnected from the grid (power switch open) and the PV modules shaded or isolated, unless otherwise indicated. |
|  | Never clean the equipment with rags made of filamentary or corrosive materials to avoid corrosion and electrostatic charges. |
|  | Do not attempt to repair the product. All repairs should be done using only eligible spare parts. |
|  | Each branch should have a circuit breaker. Central protection unit is unnecessary. |



6.6 Microinverter Replacement

a. How to remove the microinverter

- De-energize the AC branch circuit breaker.
- Remove the PV module from the rack, and cover the module.
- Check the equipment with an electric meter and make sure there is no current flowing in the DC wires between module and microinverter.
- Remove the DC connectors with DC disconnect tool.
- Remove the AC Sub Connector with AC disconnect tool.
- Loosen the fixing screws on the top of the microinverter and remove the microinverter from the PV racking.

b. How to replace the microinverter in monitoring platform

- Please note down the new microinverter's SN.
- Please make sure the AC branch circuit breaker is off, and install the replacement unit according to the microinverter installation steps.
- Go to the monitoring platform (if customer has already registered this station online), please access the "Device List" page and find the device that you just replaced. Please click "Device Maintenance" on the right side of the page, and select "Replace Device". Input the new microinverter's SN and click "Ok" to complete the station change.



7. Decommission

7.1 Decommission

Disconnect the inverter from DC input and AC output, remove all connection cable from the microinverter, and remove the microinverter from the frame.

Please pack the microinverter in the original packaging. If the original packaging is no longer available, you can use a carton box that can hold 5 kg and can be fully closed.

7.2 Storage and Transportation

Hoymiles packages are specially designed to protect components so as to facilitate transportation and subsequent handling. Transportation of the equipment, especially by road, must be done in a way that can protect the components (particularly the electronic components) from violent shocks, humidity, vibration, etc. Please dispose of the packaging elements in appropriate ways to avoid unforeseen injury.

Please examine the conditions of the components to be transported. Upon receiving the microinverter, you should check the container for any external damage and verify the receipt of all items. Please call the carrier immediately if there is any damage or if any parts are missing. In case of any damage caused to the inverter, contact the supplier or authorized distributor to request a repair/return and ask for instructions regarding the process.

The storage temperature range of microinverter is -40°C to 85°C.

7.3 Disposal

- If the equipment is not used immediately or is stored for a long period of time, make sure that it is properly packed. The equipment must be stored indoors with good ventilation and without any potential damage to the components of the equipment.
- Take a complete inspection when restarting the equipment after it has stopped operation for a long time.
- Please dispose of the microinverters properly in accordance with local regulations after they are scrapped because of potential harms to the environment.

8. Technical Data



Be sure to verify the following before installing Hoymiles Microinverter System.

- Verify that the voltage and current specifications of the PV module match those of the microinverter.
 - The maximum open circuit voltage rating of the PV module must be within the operating voltage range of the microinverter.
 - We recommend that the maximum current rating at MPP should be equal to or less than the maximum input DC current.
- The output DC power of PV module shall not exceed 1.35 times of the output AC power of the microinverter. Refer to "Hoymiles Warranty Terms & Conditions" for more information.

| Model | HMS-1600DW-4T | | | HMS-1800DW-4T | | | HMS-2000DW-4T | | |
|--|---------------|------|------|--|------|------|---------------|------|------|
| Input Data (DC) | | | | | | | | | |
| Commonly used module power (W) | 320 to 540+ | | | 360 to 600+ | | | 400 to 670+ | | |
| Maximum input voltage (V) | | | | 65 | | | | | |
| MPPT voltage range (V) | | | | 16-60 | | | | | |
| Minimum/Maximum Start-up voltage (V) | | | | 22/60 | | | | | |
| Maximum input current (A) | 4 × 14 | | | 4 × 15 | | | 4 × 16 | | |
| Maximum input short circuit current (A) | | | | 4 × 25 | | | | | |
| Number of MPPTs | | | | 2 | | | | | |
| Number of inputs per MPPT | | | | 2 | | | | | |
| Output Data (AC) | | | | | | | | | |
| Rated output power (VA) | 1600 | | | 1800 | | | 2000 | | |
| Rated output current (A) | 7.27 | 6.96 | 6.67 | 8.18 | 7.83 | 7.50 | 9.09 | 8.70 | 8.33 |
| Nominal output voltage (V) | 220 | 230 | 240 | 220 | 230 | 240 | 220 | 230 | 240 |
| Output voltage range (V) ¹ | | | | 180-275 | | | | | |
| Nominal frequency/range (Hz) ¹ | | | | 50/45-55 or 60/55-65 | | | | | |
| Power factor (adjustable) | | | | > 0.99 default 0.8 leading ... 0.8 lagging | | | | | |
| Total harmonic distortion | | | | < 3% | | | | | |
| Maximum units per 10 AWG branch ² | 4 | 4 | 4 | 3 | 4 | 4 | 3 | 3 | 3 |
| Efficiency | | | | | | | | | |
| CEC peak efficiency | 96.70% | | | 96.50% | | | 96.50% | | |
| Nominal MPPT efficiency | | | | 99.80% | | | | | |
| Night power consumption (mW) | | | | < 50 | | | | | |
| Mechanical Data | | | | | | | | | |
| Ambient temperature range (°C) | | | | -40 to +65 | | | | | |
| Dimensions (W × H × D [mm]) | | | | 310 × 185 × 40.6 | | | | | |
| Weight (kg) | | | | 4.5 | | | | | |
| Enclosure rating | | | | Outdoor-IP67 (NEMA 6) | | | | | |
| Cooling | | | | Natural convection – No fans | | | | | |
| Features | | | | | | | | | |
| Communication | | | | Wi-Fi | | | | | |
| Topology | | | | Galvanically Isolated HF Transformer | | | | | |
| Monitoring | | | | S-Miles Cloud ³ | | | | | |
| Compliance | | | | IEC 61727, IEC 62116, IEC 61683, IEC60068-2-1/-2/-14/-30, IEC/EN 62109-1/-2, IEC/EN 61000-6-1/-2/-3/-4, IEC/EN 61000-3-2/-3 | | | | | |


*1 Nominal voltage/frequency range can vary depending on local requirements.

*2 Refer to local requirements for exact number of microinverters per branch.

*3 Hoymiles Monitoring System.

10. Appendix 2:

10.1 WIRING DIAGRAM – 230VAC SINGLE PHASE:



10. Appendix 2:

10.2 WIRING DIAGRAM – 230VAC / 400VAC THREE PHASE:

